

Lunchbox Mixer

Overview

Type	Audio Mixer
Size	6HP Eurorack
Depth	.8 Inches
Power	2x5 Eurorack
+75 mV	50 mA
-75 mV	10 mA

Xerest Pola is a three-channel mixer ideal for small, on-the-go cases. It features per-channel and master volumes and mutes, a headphone out, and stereo audio out.







Lunchbox Mixer

Patch Tutorial

Patch an audio source into at least one channel on XP. Plug headphones into the HP jack. Toggle the mute switch(es) to turn individual channels on or off. Toggle the master mute switch to turn all sound off. Adjust volume of each channel and master independently.





Lunchbox Mixer

Interface

Input 1-3

Audio inputs

Mute: 1-3

Mutes individual channels

Mute: Master

Mutes all channels simultaneously.

Volume knobs

Control for each individual channel (1-3) and Master volume.

Out


AC-coupled audio output


HP

Headphone jack

Special Thanks

Shawn Jimmerson Skyler "kittyspit" King William Mathewson Mickey Bakas Tyler Thompson Alex Anderson





Lunchbox Mixer

Back Panel

Loudness Control

The Loud switch on the back panel acts as a 12 dB attenuator in the low position. If a louder output is required, gently push the switch to the up position (toward the arrow).

Special Thanks

Shawn Jimmerson
Skyler "kittyspit" King
William Mathewson
Mickey Bakas
Tyler Thompson
Alex Anderson

