



MIDI/Audio control surface with motorized faders for production









The lightning flash with arrowhead symbol within an equilateral triangle.is intended to alert the user to the presence of uninsulated dangerous voltage within the products enclosure, that may be of sufficient magnitude to electric shock to persons. Le symbol.clair avec point de fi che I intrieur d un triangle quilat ral est utilis pour alerter lutilisateur de la pr sence I int rieur du coffret de vottage dangereux non isol d'ampleur suff

exclamation point within an equilateral triangle is intended to alert the user of the presence of important operating and maintenance (serviving) instructions in the literature accompanying the appliance. Le point dexclamation i int rieur d'un triangle quilat ral est employ pour alerter les utilisateurs de la prsegoe d'instructions importantes pour le fonctionnement et l'entretien (service) dans le livret d'instruction accompanant la popari I.

Important Safety Instructions

1. Read this manual thoroughly before using this unit.

TERETIEN AU PERSONNEL QUALIFIE

AVIS: POUR EVITER LES RISQUES D'INCENDIE OL

D'ELECTROCUTION, N EXPOSEZ PAS CET ARTICLE A LA PLUIE OU A L'HUMIDITE

- 2. Keep this manual for future reference.
- Take notice of and comply with all warnings included in the user's manual or indicated on the appliance.
- 4. Follow all instructions included in this manual.
- Do not expose this unit to rain or moisture. Avoid having water or other liquids spilled on this unit.
- When cleaning the cabinet or other parts of this appliance, use only a dry or slightly damp soft cloth.
- 7. Do not block any ventilation openings or interfere with the proper ventilation of this unit. Install in accordance with the manufacturer's instructions.
- 8. Do not use or store near any heat sources such as radiators, heat registers, stoves, or other heat-producing appliances.
- 9. Do not interfere with the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. These are designated for your safety. If the provided plug does not fit into your outlet, consult an electrician.
- 10. Protect the power cord from being walked on or otherwise damaged by items placed on or against them. Particular attention should be given to the plugs, receptacles, and the point where the cord exits the appliance.
- 11. To avoid the risk of electrical shock, do not touch any exposed wiring while the unit is in operation.
- 12. Only use attachments/accessories specified by the manufacturer.
- Unplug this unit and all connected electrical equipment during lightning storms or when left unused a long period of time.
- 14. Refer all servicing to qualified service personnel. Servicing is required when the appliance has been damaged in any way or fails to operate normally.

WARNING: To reduce the risk of fire or electric shock, do not expose this unit to rain or moisture

Contents

Introduction	4
What's in the package?	4
Features	5
Top Panel Layout	6
Rear Panel Layout	8
Bottom Panel Layout	9
Getting Started (Connected with QconEX G2 (1 - 3units)	10
Cubase	14
Logic Pro	16
Pro Tools	18
Getting Started	20
Connecting Your QconEX G2 Controller	20
Cubase	22
Nuendo	23
Logic Pro	24
Samplitude	25
Bitwig	27
Reason	28
Reaper	29
Studio One	30
Ableton Live	31
Pro Tools	32
Audition	33
Sonar	34
iMap [™] Software for Mac OS X	36
Installing iMap [™] Software for Windows	36
iMapTM QconEX G2 software panel	39
Connections	40
Firmware upgrade	41
Restore the factory default settings	44
Specifications	45
Services	46

Introduction

Thank you for purchasing the ICON ProAudio QconEX G2 Midi/Audio control surface. We sincerely trust this product will provide years of satisfactory service, but if anything is not to your complete satisfaction, we will endeavor to make things right.

In these pages, you'll find a detailed description of the features of the QconEX G2, as well as a guided tour through its front and side panels, step-by-step instructions for its setup and use, and full specifications.

You'll also find a warranty card enclosed - please don't forget to fill it out and mail it so that you can receive online technical support at: www.iconproaudio.com, and so we can send you updated information about these and other ICON ProAudio products in the future. As with most electronic devices, we strongly recommend you retain the original packaging. In the unlikely event the product must be returned for servicing, the original packaging (or reasonable equivalent) is required.

With proper care and adequate air circulation, your QconEX G2 will operate without any trouble for many years. We recommend that you record your serial number in the space provided below for future reference.

Please write your serial number here for future reference:
Purchased at:
Date of purchase:

What's in the package?

- QconPro EX G2 USB-MIDI Controller x 1pc
- CD x 1

App software – iMap (Mac & Windows)
User manual & QSG


- Quick Start Guide x 1
- USB2.0 Cable x 1
- AC adaptor x 1pc
- Screwdriver x 1

Features



- 8 touch-sensitive motorized channel faders
- 12-segment LED level metering for channels
- 8 x dual function encoder knobs (Enter & rotate)
- 11-segments LED surrounding the encoders to indicate the rotating position
- Large backlit LCD to display channel name, control values etc. for each channel
- Illuminated buttons for each channel including Rec-enable, Solo, Mute, Select and Monitor
- MackieControl and HUI Universal emulation
- iMap Self midi mapping software is provided for user-defined mode (MIDI Learn)
- Expandable to 32-channel control surface with 3units of QconEX G2 and a QconProG2
- User A & User B 1/4" TRS connectors for connecting with pedals
- Class-compliant with Windows XP, Vista (32-bit), Windows 7/8/10 (32-bit & 64-bit), and Mac OS X (IntelMac)
- USB 2.0 high speed connectivity
- Firmware upgrade available simply via USB connection and iMap software
- Robust aluminum and metal casing with Kensington lock port

Top Panel Layout



Note: Function operates slightly difference between DAWs. Please refer to your DAW manual for each function and overlap the provided labeling template according to your currently used DAW. The following description is based on the functions that operate in Apple Logic.

1. LCD backlit display

The two-line backlit LCD display shows the parameter values as you adjust them and also provides feedback about channel selections, operating modes, and more.

2. Channel faders

The eight 100mm motorized faders are generally used for controlling the track volume of your DAW. Depending on your DAW, you may use the "Flip" button to switch the function of these faders to change other settings. They are all touch sensitive to allow override automation the moment you touch a fader. Also, they are motorized; they will automatically move to reflect the current level of the selected channels in your DAW application. Any automation recorded in a project will be reflected by the fader positions. Any parameter adjustments made with these faders will be displayed directly above on the LCD display.

3. Channel level metering

The 12-led meter shows the associated channel level.

4. Dual function encoders

The dual function encoders act as push-button and rotary controls.

When an encoder is pressed, it may be used to change modes of operation or to change what appears in the display above the channel strips. When an encoder is rotated, depending on its assigned function, it can be used to adjust a channel's pan, send level, or plug-in parameters.

5. Encoder LED

The 11-LED's surrounding the encoder light up to indicate the relative position of the rotation without having to look at your computer.

6. Control buttons

Recording channel control buttons section

REC buttons - Activate and deactivate the recording state of the associated channel. The switch will light red when the channel is armed. **SOLO buttons -** Activate and deactivate the solo state of the associated

channel. The switch will light green when the channel solo state is on and other channels will be muted. You can solo multiple channels by pressing SOLO buttons on additional channels.

MUTE buttons - Activate and deactivate the mute state of the associated channel. The switch will light blue when the channel is muted.

SEL buttons - The SEL buttons activate the associated channels in the DAW software in order to perform a specific operation (for example, when adjusting EQ with the ASSIGNABLE ENCODERS, the SEL switch will be used to choose the channel you want to adjust). The switch will light red when the channel is selected.

7. DAW Selector section

QconEX G2 has built-in Mackie Control, LogicPro protocols & HUI for different DAW's such as CubaseTM, SamplitudeTM, Ableton LiveTM, Logic ProTM and Pro ToolsTM. By selecting the correct Mackie control (HUI/LogicPro) protocol, QconEX G2 will automatically map the major functions and work seamlessly with that DAW.

<< / >> buttons - These arrow buttons are used to scroll through the mode list. The name of the mode will display on the LCD.

DAW button - Press to enter the mode selection.

To change your QconEX G2 Control mode, turn the power switch off and on to enter the Control selection mode. Select your desired mode from the list with the "<<" / ">>" buttons.

(Note: You have to select the "Unit Number" for QconEX G2 before you select the DAW.)

Tips: The DAW button cannot be activated if DAW software is running.

Tips: QconEX G2 will memorize your last selected DAW mode and re-enter the same mode a few seconds after it has been switched on. (i.e. DAW mode selection is not needed if the last mode is being used.)

Rear Panel Layout



1. User A / User B 1/4" TRS connectors

These 1/4" TRS connectors are able to connect to foot pedals (SPD-01) to activate your selected functions. To set their parameters, select USER A and USER B parameters in Mackie control mode.

2. USB port


Connect your QconEX G2 to your Mac/PC via this USB port.

3. 12V/5A power adapter

Connect the provided power adapter here.

(Note: QconEX G2 is not able to work without the provided power adapter connected. The USB bus power is not able to provide sufficient power supply for QconEX G2.)

Bottom Panel Layout




1. LCD contrast adjustment

Rotate the adjustment knob with the provided screwdriver to adjust the contrast of the LCD. Rotate anticlockwise to reduce the contrast and clockwise will increase.

Getting Started (Connected with QconEX G2 (1 - 3units)) Connecting Your QconPro G2 Controller

1. Connect the QconPro G2 to your Mac/PC via the USB port
Choose a USB port on your Mac/PC and insert the wide (flat) end of the USB
cable. Connect the cable's other end to the QconPro G2. Your Mac/PC should
automatically "detect" the new hardware and notify you that it is ready to use.


(**Tips:** We recommended that you use ICON's OneHub USB hub, which allows you to connect up to 3 units of QconEX G2, if you are not connecting QconEX G2 directly to your computer's USB port.)




2. Select the DAW.

Press <</>> to scroll through the mode list after pressed the "DAW" button to make the selection.


1 QconEX G2 (1)



2 QconEX G2 (2)



3 QconEX G2 (3)



4 QconPro G2



3. Setup your DAW

The QconPro G2 has built-in Mackie Control, LogicPro and HUI protocol which will save you considerable trouble in setting up the device at your DAW. Simply add the "Mackie Control" or "HUI" device under the "MIDI Controller" on your software. After the Mackie Control or HUI device has been added, select QconPro G2 controller as your MIDI input and output device in your DAW.

For the software below, please use Mackie Control Nuendo/CubaseTM, SamplitudeTM, BitwigTM, ReasonTM, ReaperTM, Studio OneTM and Ableton LiveTM.


The software below, please use logic Pro Mackie Control

or the software below, please use HUI Pro Tools[™].

(**Tips:** You may also refer to our website at **www.iconproaudio.com**, where you'll find set up illustrations for different DAW's in each controller (QconEX G2) product page's "Setup demo" section.


For DAW's not on our setup demo list, please refer to your software user manual for hardware setup.)

Cubase











Logic Pro













Pro Tools



















Getting Started Connecting Your QconEX G2 Controller



Connect the QconEX G2 to your Mac/PC via the USB port. Choose a USB port on your Mac/PC and insert the wide (flat) end of the USB cable. Connect the cable's other end to the QconEX G2. Your Mac/PC should automatically "detect" the new hardware and notify you that it is ready to use.


(Tip: We recommended that you use ICON's OneHub USB hub, which allows you to connect up to 3 units of QconEX G2, if you are not connecting QconEX G2 directly to your computer's USB port)

Select the "Unit number"

Press <</>> to scroll through "Unit number 1 to 3" and press the "DAW" button to confirm. You may connect up to a maximum of 3 units of QconEX G2.

Select the DAW

Press <</>>> to scroll through the mode list after pressed the "DAW" button to make the selection.



1. Setup your DAW

Activate the ICON ProAudioQconEX G2 controller in your DAW or MIDI software using "MIDI Setup" or "MIDI Devices".


For example: ,Cubase[™] and Nuendo[™], choose Mackie Control at the "Device List".

(Note: Every application does this a little differently, so refer to your software user manual for the settings.)


Cubase










Nuendo










Logic Pro

















Samplitude




24










Bitwig









Reason





Reaper




Studio One










Ableton Live







Pro Tools






Audition







Sonar










iMap[™] Software for Mac OS X

Please follow the procedures below step-by-step to launch your $iMap^{TM}$ software to Mac OS X.

1. Insert the Utility CD in your CD-Rom and double click "QconEX G2 iMap" icon.



Tip: By "dragging and dropping" the "QconEX G2 iMap" icon into the "Applications" folder, you can create an "iMap" shortcut on your Mac's desktop.

Installing iMap[™] Software for Windows

Please follow the procedures below step-by-step to install your iMap[™] software.

- 1. Turn on your PC.
- 2. Insert the Utility CD in your CD-Rom.

After you have inserted the CD into your CD-Rom, an installation screen should appear as shown in diagram 1; click "Install".

(**Note:** If the Installation screen do not appaer automatically. Go to the CD folder and double click "Setup".)


3. Setup Wizard appear

(Note: Setup wizard appears, please click "Next")



4. Choose Install Location

(Note: Choose your preferred install location for iMapTM or use the default location and click "Next")



Select shortcut

(Note: Select the start menu folder in which you would like to create the iMapTM shortcut. Then click "Next".)



Diagram 4

6. Create a shortcut on your desktop

(Note: Please uncheck the box if you do not want to place a shortcut icon on your desktop for iMapTM; otherwise click "Next")




7. iMap[™] begins installation (Note: The iMap[™] installation has now started, wait for it to finish. Then click "Finish".)



8. Installation finished

(Note: Click "Finish" to complete the iMapTM software installation.)




iMapTM QconEX G2 software panel

1. "Firmware Upgrade" button

Click this button to enter into the firmware upgrade window for QconEX G2. Please refer to P.xx for the firmware upgrade procedure.

Firmware




Step 1: Connect the ICON product using a USB connection. Press the "MIDI Device" button at the top to select your connected ICON product as the "MIDI In and Out" device in the pull-down menu.

(Note: If your connected ICON product model name does not appear on the pull-down menu, select "USB Audio" as the MIDI In and Out device.)

- Step 2: Click the "Update" button.
- Step 3: Press the "MIDI Device" button at the top to select your connected ICON product as the "MIDI In and Out" device at the pull-down menu.
- Step 4: Click the "Open File" button to browse the new firmware file.
- Step 5: Click the "Download" button to upload the firmware


(Warning: The firmware upload process MUST be completed and not be interrupted during the file upload, otherwise the firmware may not be rewritten again.)

Connections





Firmware upgrade


QconPro G2 functional firmware upload procedure



























Restore the factory default settings

To restore your QconEXG2 settings to factory default, simply launch iMap and import the original settings (i.e. without making any changes) to the device through the following steps.

- 1. Connect QconEX G2 with the provided USB cable and launch iMap software.
- 2. Click the "MIDI Device" button and select "QconEX *G2*" as the MIDI input and output device.

Note: If QconEX G2 does not appear on the pull down menu, select USB audio
as the MIDI I/O device.

- 3. Click "Send Data" to upload the setting to your QconEX G2.
- 4. Close iMap, and then turn the QconEX G2 power of off & on again.

Specifications

Connector: To computer USB connector (standard type)

To extender USB connector (B-Type)

Power supply: 12V/2.5A DC

Current consumption: 2A or less

Weight: 5.015kg (11lb)

Dimensions 457(L) x 203(W) x 456.6(H)mm


17.99"(L) x 7.92"(W) x 17.97"(H)

Services

If your QconProEX G2 needs servicing, follow these instructions.

Check our online help centre at http://support. iconproaudio.com/hc/en-us,for information, knowledge, and downloads such as:

- 1. FAQ
- 2. Download
- 3. Learn More
- 4. Forum



Navigate to http://support.iconproaudio.com/hc/en-us and then sign in to submit a ticket or click "Submit a ticket" without the need to sign in.

As soon as you have submitted an enquiry ticket, our supporting team will assist you to resolve the problem with your ICON ProAudio device as soon as possible.

To send defective products for service:

- Ensure the problem is not related to operation error or external system devices.
- 2. Keep this owner's manual. We don't need it to repair the unit.
- Pack the unit in its original packaging including end card and box. This is very important. If you have lost the packaging, please make sure you have packed the unit properly. ICON is not responsible for any damage that occurs due to non-factory packing.
- Ship to the ICON tech support center or the local return authorization. See our service centres and distributor service points at the link below:

If you are located in Hong Kong Send the product to:

Unit F, 15/F., Fu Cheung Centre,

ASIA OFFICE: No. 5-7 Wong Chuk Yueng Street, Fotan, Sha Tin, N.T., Hong Kong.

If you are located in US Send the product to:

ICON ProAudio Service Centre > 611 Potomac Place; STE 102

> Smyrna, TN 37167

If you are located in Europe Send the product to: **ICON Europe GmbH** Am Spitzberg 3 15834 Rangsdorf Germany

Telephone: +49-(0)33708-933-0 Fax: +49-(0)33708-933-189

E-Mail: info@sound-service.eu

5. For additional update information please visit our website at:

www.iconproaudio.com









www.iconproaudio.com



support.iconproaudio.com



www.twitter.com/iconproaudio



www.instagram.com/iconproaudio



www.facebook.com/iconproaudio



www.youtube.com/iconproaudio